

Cloth Cord Instructions: MX 2100 Series



1) Add 8" to Cloth Cord Length & Cut Cord, Slide Outer Cloth Cover back on Cord.



2) Mark 4" back around Cord ensuring to not cut inner wires.



3) Bend Cord & remove outer Jacket, 3 conductor wires will be exposed. (White, Black & Green)



4) Slide Outer cloth cover over wires.



6) Ready to thread through Strain Relief on Canopy.



5) Use a Lighter to melt Outer Cloth cord .5" from inner Cord & remove. (**this only takes a second.**)

Helpful Tip: If wire is frayed use lighter flame to remove.



Use Caution when using Razor Blade & Lighter